


YEALINK T23P






THE T23G IS A COST EFFECTIVE IP BUSINESS PHONE FEATURING AN INTUITIVE USER INTERFACE WITH SECURE PROVISIONING AND HD AUDIO FOR EXCELLENT VOICE QUALITY. THIS PHONE IS IDEAL FOR THOSE WORKING IN SMALL AND LARGE OFFICE ENVIRONMENTS REQUIRING GIGABIT ETHERNET AND ACCESS TO A VARIETY OF ENHANCED FEATURES.































HANDSET COMPONENT

	ITEM	DESCRIPTION
1	LCD Screen	Shows information about calls, messages, soft keys, time, date and other relevant data: <ul style="list-style-type: none"> • Call information — caller ID, call duration • Icons • Missed call text or second incoming caller information • Prompt text (for example, "Saving config file!") • Time and date
2	Power Indicator LED	Indicates phone power status and phone status

3	Line Keys	Use these keys to activate up to three accounts and assign various features.
4	Soft Keys	Label automatically to identify their context-sensitive features.
5		Scroll through the displayed information.
		Confirms actions or answers an incoming call.
		Cancels actions, rejects incoming calls, mutes or un-mutes calls.
6	MESSAGE key	Indicates and accesses voice mails
7	HEADSET key	Toggles the headset mode.
8	TRAN key	Transfers a call to another party
9	RD key	Redials a previously dialed number.
10	Speakerphone key	Toggles the hands-free speakerphone mode.
11	Volume key	Adjusts the volume of the handset, headset, speaker, and ringer.
12	Keypad	Provides the digits, letters and special characters in context-sensitive applications.
13	Speaker	Provides ringer and hands-free (speakerphone) audio output.
14	Hookswitch Tab	Secures the handset in the handset cradle when the IP phone is mounted vertically.
15	Hookswitch	Picking up the handset from the handset cradle, the hookswitch bounces and the phone connects to the line, laying the handset down on the handset cradle, the phone disconnects from the line.

HANDSET ICONS

ICON	DESCRIPTION
	Network is unavailable
	Private line registers successfully
	Register failed/Registering
	Hands-free speakerphone mode
	Handset mode
	Headset mode
	Multi-lingual lowercase letters input mode
	Multi-lingual uppercase letters input mode

	Alphanumeric input mode
	Numeric input mode
	Multi-lingual uppercase and lowercase letters input mode
	Voice Mail
	Text Message
	Auto Answer
	Do Not Disturb
	Call Forwarded/Forwarded Calls
	Call Hold
	Call Mute
	Ringer volume is 0
	Keypad Lock
	Received Calls
	Placed Calls
	Missed Calls
	Recording box is full
	A call cannot be recorded
	Recording starts successfully
	Recording cannot be started
	Recording cannot be stopped

- **MAKING A CALL**

Pick up the Handset to make a call.

Dial Number Directly : Dial the number directly, and press the # key to call out

Re-dial: Dial the RD Button to dial out the last called number directly

- **ANSWERING A CALL**

Answering an incoming call in the following ways:

If you are on another call, press the Hold key to answer it

If you are not on another call, just lift the handset to answer it

You can also press the Mute button to deny the incoming call

- **MUTING A CALL**

Press the Mute button during a conversation to mute the call, and press it again to get the microphone to return to normal conversation

- *Volume Adjustment*

During the call, you can press the volume adjustment bars to adjust the volume

- *Putting a Call on Hold*

Press the HOLD button to put your active call on hold

If there is only one call on hold, press the HOLD key again to retrieve it

If there are two calls on hold, press HOLD to put the current call on hold, and retrieve the third party

- **VOICE MAIL**

The Presence of new Voice Mail messages will be indicated by the LED, users can pick up the handset and dial the concatenated code to get the voicemail in the server

- **CONFERENCE CALL**

Press the Hold key during an active call

The first call is placed on hold. You can dial the third number, then press # key to call out.

When the call is answered, press the Redial key to establish a three-party conference.

Hang up to disconnect the conference call

- **CALL TRANSFER**

There are three ways to transfer the call: Blind Transfer, Attended Transfer and Semi- Attend Transfer.

- *Blind Transfer:*

Press TRAN to put the caller on hold

Dial the destination extension

Press TRAN

Replace receiver

- *Announced Transfer:*

Press TRAN to put the caller on hold

Dial the destination extension and press #

Announce the call to the receiving party and then either press TRAN or replace the receiver

Call will be transferred

- *Semi – Announced Transfer:*

Press TRAN to put the caller on hold

Dial the destination extension and press #

When you hear the ringing tone, hang up or press the TRAN button to complete the transfer

POWER INDICATOR LED

LED STATUS	DESCRIPTION
Solid red	The phone is initializing.
Fast flashing red (300ms)	The phone is ringing.
Slow flashing red	The phone receives a text message or voice mail.
Off	The phone is powered off The phone is idle The phone is busy The call is muted The call is placed on hold or held

LINE KEY LED

LED STATUS	DESCRIPTION
Solid green	The line is in conversation. The line is seized. The call is muted
Fast flashing green	The line receive an incoming call.
Slow flashing green	The call is placed on hold.
Off	The line is inactive.